


TECHNICAL DATA

MODEL	DISPLACEMENT cfm	MAX. PRESSURE psig	RPM	MOTOR WITH THERMIC PROTECTOR hp	WEIGHT IN lbs	DISCHARGE SIZE
MSV 6	6,04	100	1730	1	64	1/4" NPT




BARE PUMP'S PARTS

No.	CODE	DENOMINATION	QUANTITY	No.	CODE	DENOMINATION	QUANTITY
1	830.0185-2	Protecting screen	01	15	830.0695-0	Needle bearing with grease seal	02
2	709.0251-6	Fan	01	16	830.0694-0	Connecting rod	02
3	709.0260-5	End bracket	01	17	830.0242-5	Ring	02
4	830.0187-9	60 Hz electric motor	01	18	830.0692-0	Ø46,5mm piston	02
5	830.0289-1	Stud	01	19	709.0242-7	Cylinder	02
6	019.0017-0	6203 2Z bearing	01	20	*	UNC 5/16"x 3/4" LT head screw	08
7	60154035	6203 2RS1 bearing	02	21	830.0192-5	Gasket	01
8	382.0025-9	6304 2Z bearing	01	22	830.0181-0	Valve plate kit	02
9	013.0217-5	Key	01	23	830.0641-0	Valve plate	02
10	709.0257-5	Crankcase	01	24	809.0984-0	Filter element	02
11	709.1252-0	Crankcase cover with breather hole	01	25	809.0997-0	Air filter	02
12	*	UNC 1/4"x 1/2" LT head screw	04	26	709.0245-1	Cylinder cover	02
13	028.0035-7	Crankcase breather (sse note)	01	27	*	UNC 1/4"x 1.1/2" LT head screw	08
14	830.0193-3	Crankshaft	01	-	003.0004-7	NPT 1/4"x3/8" elbow	02

* Part available in the market - not sold by Schulz S.A.
Note: available for products manufactured until April/2000.

DIMENSIONS

MSV 6



	A	B	C	D	E	F	G	H
mm	440	76	8,5	300	124	31	89	230
inch	17.3	3	0.33	11.8	4.9	1.22	3.5	9.05

INSTALLATION AND OPERATION INSTRUCTIONS

INSTALLATION AND LOCATION

1. Installation: Install the compressor in a covered, well ventilated area, free of dust, toxic gases, humidity or any other kind of pollution. The compressor should be located no closer than 32" (800mm) from a wall or any other obstacle that could interfere with the air flow through the fan. This distance will also make maintenance easier. Place the compressor on a leveled surface. Rotation of the flywheel must be in the direction of the arrow cast into the flywheel. The maximum ambient temperature recommended while working is 104°F or 40°C. If necessary, install an exhaust fan to guarantee fresh air and to dissipate heat.

Before making the electrical connections, check oil level and top-up lubricating oil. For type of oil, see table at the end of these instructions.

2. Electrical connection: The country's valid electrical standards must be followed regarding Low Voltage Electrical Installation.

OPERATION

1. Start: turn on the electrical start key and let your compressor run for about 10 (ten) minutes, what will keep the tank's internal pressure or compressed air around 20 psig. This will optimize a homogeneous lubrication of the parts.

LIMITED WARRANTY

All component parts on your SCHULZ compressor are warranted to be free of defects in workmanship and material for a period of one year. Transportation charges are responsibility of the purchaser. This warranty extends to the original purchaser of the compressor only.

There are no express warranties except as contained in this limited warranty statement and implied warranties, including those of merchantability and fitness for a particular purpose, are limited to the period of warranty.

Our liability is limited solely to replacement of nonconforming parts as set forth herein and does not include any liability for any incidental, consequential, or other damages of any kind. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

SCHULZ

Schulz of America, Inc.
320 A Northpoint Parkway
Acworth, GA 30102
Phone # (770) 529-4731 / 32
Fax # (770) 529-4733
E-mail: sales@schulzamerica.com

MAINTENANCE

WARNING

Turn off power before servicing and be sure the air tank is unloaded. These instructions are based on normal operating conditions. If the compressor is located in an exceedingly dusty area, increase the frequency of all inspections.

DAILY

- Inspect the compressor visually.
- Drain moisture from the piping system.
- Be sure there is no excessive or unusual vibration or noise.

WEEKLY

- Remove and clean intake air filters; do not wash the filter element.
- Clean cylinders externally, cylinder head, motor, fan blade, tubing, and tank.
- Safety valve should be tested manually to see if it is working properly.

MONTHLY

- Check entire system for air leakage around fittings, etc by using water and soap lather.
- Check the pressure switch operation.

QUARTERLY

- Change the air filter element every 300 working hours or quarterly. (Whichever occurs first).
- Fasten cap screws and nuts as required.

EVERY 6 (SIX) MONTHS

- Lubricate the connecting rod(s)'s upper bearing.

ANNUALLY

- Test and calibrate the pressure switch, pressure gauge, and safety valve according to their own technical standards. These parts must be removed from the tank and pump to be tested.
- Inspect and clean the suction and discharge valve(s) plate(s) every 1000 (one thousand) working hours (whichever occurs first), located between the cylinder and its cover and, if necessary, replace it (them) according to the operation conditions.

NOTE:

Replace the connecting rod(s)' lower bearing every 1000 (one thousand) working hours

LUBRICATION

Clean the connecting rod(s)'s upper bearing. Re-lubricate it (them) using Barrierta L55/3 grease.

DISTRIBUTOR

